

# PLEASE READ BEFORE USE




FAILURE TO READ THE MANUAL WILL VOID THE WARRANTY

**RETAIN FOR FUTURE REFERENCE. READ CAREFULLY.**

## GETTING STARTED:

- Plug the coil into the control box and ensure it is fully secure
- Plug the power cord into a properly grounded/dedicated outlet. Never use a two prong adapter, extension cord or relocatable power tap (outlet/power strip)
- Place your enail compatible nail onto your rig. Install the coil onto the nail.
- Press the black power switch on the back of the unit to turn the box ON/OFF. Press the red power switch to turn the coil ON/OFF
- The unit will overshoot the set temperature on the initial startup, allow the unit to run for a few minutes at one set temperature for maximum calibration and to stabilize







## HOW TO SET THE TEMPERATURE:

- All HIGH5 units are pre-programmed and preset to reach 710°F. **For all units only use the  and  arrows to set the desired temperature.** Standard units have a temp range of 0°F to 1200°F. Recommended usage is below 1000°F. Hold the button down to increase number changing speed. The numbers will flash/blink indicating the desired temperature is set. **Do not press the "SET/O" or  buttons. These two buttons are for programming the enail and should not be touched unless you are familiar with operating the unit. Each unit already comes preprogrammed.**



**WWW.HIGHFIVEVAPE.COM**

## HOW TO SET TEMPERATURE FOR PELICAN ENAILS:

- Press  Toggle Switch for Power
- Press /AT Button to Activate Temperature Control
- Press   Buttons to Raise & Lower Desired Temperature
- Press /AT Button to Navigate Through Each Degree
- Press  Button to Lock Desired Temperature In Place

## COIL:

HIGH5 offers a standard 1 year warranty on all Enail coils. To ensure your coil lasts as long as possible avoid putting excess pressure on the coil specifically the wiring. Frequent bending/pulling/bundling can damage the internal wiring. Using the coil at temperatures near 1000°F for long periods of time(5 mins+)can significantly shorten the lifespan of your coil. Your coil will turn a dark black almost burnt look if used above 1000°F and is easily identifiable. If you need to clean your nail we recommend using a torch or a cleaning solution as Enails are not meant to clean nails. Coils will need to be replaced once they reach the end of their lifespan; this is true with all Enails. Once your coil nears the end of its lifespan the display will show EEEE indicating a new coil is required. If your coil stops working within 1 year please contact us directly through our website and a replacement will be provided free of charge once the problem is verified. **ONLY USE HIGH5 COILS WITH HIGH5 ENAILS**, many other coils are wired differently and will not work with our units. The warranty for coils only covers failure of electronics, it does not cover any forms of accidental damage, theft, misuse or neglect such as:

- Any forms of physical damage
- **Manually enlarging the coil to fit a nail**
- Exposing the coil to liquids/gel/moisture
- Using the coil with an Enail from another brand
- Modifying the coil in anyway such as bending the rod
- Using the coil at temperatures near 1000°F for an extended period of time resulting in a burnt/black appearance.

**WWW.HIGHFIVEVAPE.COM**

## **CONTROLLER/BOX:**

HIGH5 offers a standard 1 year warranty on all Enail controllers/boxes. This includes all Enail models. ***ONLY USE HIGH5 COILS WITH HIGH5 ENAILS.*** If your controller stops working within one year please contact us directly through our website and a replacement will be provided free of charge once the problem is verified. The warranty for the Enail controller only covers failure of electronics, it does not cover any forms of accidental damage, theft, misuse or neglect including:

- Any forms of physical damage
- Opening the Enail housing/encasing
- Not reading the manual before use
- Using coils or power cords not from HIGH5
- Exposing the unit or its electrical components to any liquids/gels/moisture

## **QUARTZ NAILS/BANGERS:**

It is recommended that you remove the coil from your quartz nail immediately after turning the unit off. When the unit is turned on the coil heats up and expands but once turned off the coil starts to cool and will contract and squeeze the quartz nail/banger potentially breaking it. Removing the coil will eliminate the chance of the nail breaking significantly. When using a quartz nail/banger be careful when using a dabber, it is recommended that you avoid scraping/hitting the dish, stem and walls of the nail and instead let the oil melt into the dish in order to prolong the life of the quartz nail.



## **OPERATING SAFELY:**

**USE WITH CAUTION:** Must be 18 years of age or older to operate. Never leave the unit unattended while powered on or plugged in. The coiled heater is **HOT** and will remain hot after usage. Refrain from touching the coiled heater for a minimum of 5 minutes after each usage.

**[WWW.HIGHFIVEVAPE.COM](http://WWW.HIGHFIVEVAPE.COM)**